



This remote did not have an AUX button
The CD/DVD port didnot work

Set the receiver to TUNER at 88.5 MHz for announcer.
Set the receiver to VID2 for Singing Pumpkins.

Kenwood receiver VR707



Receiver in Gift Shop

PA Gift Shop
10/15/24

Drawn by: Ted Dunn
Approved by: *A. Eisenstein*